






Soft Starter – SCR Connections



- Soft starter models up to 255 A (inclusive) use SCRs.
- The soft starter may be fitted with Semikron or Eupec SCRs. SCR spare part kits may include either Semikron or Eupec SCRs. The Semikron and Eupec SCRs are fully interchangeable and can be mixed within the same soft starter.
- Connect the firing looms according to the diagrams below.

 <p>18 ~ 60 A 7.5 ~ 30 kW</p>	<p>75 ~ 100 A 37 ~ 55 kW</p>	<p>140 ~ 200 A 75 ~ 110 kW</p>
 <p>23 ~ 76 A</p>	<p>97 ~ 145 A</p>	<p>170 ~ 255 A</p>
 <div style="display: flex; justify-content: space-around;"> <div data-bbox="241 1045 324 1252"> <p>SEMİKRON</p> </div> <div data-bbox="649 1045 732 1252"> <p>EUPEC</p> </div> </div>	 <div style="display: flex; justify-content: space-around;"> <div data-bbox="884 1021 1041 1268"> <p>SEMİKRON</p> </div> <div data-bbox="1220 1021 1377 1268"> <p>EUPEC</p> </div> </div>	 <div style="display: flex; justify-content: space-around;"> <div data-bbox="1512 1021 1691 1300"> <p>SEMİKRON</p> </div> <div data-bbox="1892 1021 2072 1300"> <p>EUPEC</p> </div> </div>